



## 10 easy steps to fitting your Hydro Brush

To fit the Hydro Brush you first need to fit a suitable tap or connector into your cold water mains supply that feeds your toilet cistern. If you are employing a plumber to do this job then he will know what to do from this point onwards. If you are fitting the Hydro Brush yourself using the fittings supplied you need to follow the instructions below.

- 1) Unscrew main body from saddle and clamp the saddle around a small section of the pipe and tighten screws with a screw driver.
- 2) Move locking nut towards the main body as far as it will go to expose the maximum amount of thread.
- 3) Screw main body into the saddle until you feel resistance. Continue turning the main body until this resistance reduces.
- 4) Continue to turn the main body until you feel it get slightly more difficult to turn and then stop.
- 5) Position the main body in the position you wish it to remain by turning it further and then stop.
- 6) Tighten the locking nut onto the clamp by hand and when tight finish off with a spanner but, do not over tighten.
- 7) Turn the tap on to allow the check that water is flowing and to insure the pressure is equalised.
- 8) Attach the Hydro Brush hose to the tap by hand only, taking care to make sure you use the washer supplied.
- 9) Attach the Hydro Brush unit to the other end of the Hydro Brush hose and turn on the tap. The Hydro Brush is now ready to be used. If you are fitting the wall bracket move onto section 10 below. If not try out your Hydro Brush and see how easy it is to use.
- 10) If you are fitting the Hydro Brush head wall bracket you have the option to use the self sticking pads or to screw this unit into the wall.